

Spencer Walcott Vinyl Sliding Patio Doors

HOW TO REVERSE A DOOR HANDING

SPENCER
WALCOTT

REVERSING THE JENNIE KREGER DOOR HANDING

- A. Lift operating panel out of door.
- B. Place panel on side, remove rollers, and reinstall rollers in opposite edge of door panel.
- C. Remove 2 screws from top and bottom of stationary door panel at center of door. Remove horizontal screws only. DO NOT remove vertically installed screws.
- D. The stationary panel can now be removed from the outside of the door by lifting the panel up and out.
- E. Remove keeper from side jamb of frame.
- F. Remove vinyl jamb cover filler from opposite side jamb.
- G. Reinstall keeper in opposite side jamb using its original position as a reference.
- H. Reinstall jamb cover on opposite side jamb.
- I. Remove vinyl head and sill starting at open end at center of door.
- J. Reinstall both on opposite side of frame snapping them into the frame.
- K. Move 2 sash stops (1 top 1 bottom) to opposite side of door track channel.
- M. “Cartwheel” stationary door panel and reinstall into opposite side of door frame from the exterior using screws from removal process.
- N. Screw holes should line up for reinstalling panel
- O. Reinstall operating panel into frame by inserting head of panel into frame first and then setting roller end of panel onto track.
- P. “Cartwheel” screen and reinstall into exterior of frame.

